



The Snow Defender™ 6500 is designed for standing seam roofing only. It is an all stainless steel part. And is powder coated to match the metal roofing. It is designed to fit standing seam panels in seam width up to 3/8 and seam heights up to 1-3/4”.

Installation Instruction:

Take the guard and a 7/32 hex bit. Using the 7/32 hex bit unscrew the set screws till they are flush on the inside wall. Next take the guard and put it on the seam of the roof. Guard shall be placed with the set screws towards the ridge of the roof and the blade being towards the eave. Next take the 7/32 hex bit and tighten set screws. After tightening set screws, torque the set screws. Recommended torque is 220 inch pounds although some panels may vary.

Notice; Most Electric & Cordless drill's will not achieve 220 inch pounds. It is recommended to use a torque wrench.

Placement;

It is recommended to install the guards in a staggered pattern. **For a detailed recommendation based on your roof dimensions go to www.snow-defender.com and see the calculator page or call your distributor.**

